

andron®

andronic® 2060 intelligent controls

OPERATING INSTRUCTIONS



Version	V 1.4
Date	07.04.2011
Author	Pa/Scho
Editing/Illustrations	Pa
Filename	operating_instructions_andronic_2060_v1_4.doc
Trademark	All product names or trademarks are properties of their respective owners.
Copyright	© andron GmbH 2011. All Rights Reserved. Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design.
Validity	There could be additional functions running in the control who are not mentioned in this documentation. It insists no claim for this functions, in case of a new delivery or a service case. All rights are reserved with respect to the content of this documentation and the availability to the product.
Published by	andron GmbH, Schlätterstraße 2, 88142 Wasserburg, Germany Telephone +49 (0) 8382/9855-0, Fax +49 (0) 8382/9855-50 e-Mail: info@andron.de www.andron.de

Table of contents

Table of contents	3	PASSW	18
Revisions	3	Teach	18
Notice	4	Load automatic program (AUTOM)	18
Safety notes	4	DNC function (DNC)	18
Warning notes and symbols	4	G&M-CNV	18
Use as directed	5	Tool management	19
Introduction	5	Overview of functions	19
Field of applications	5	Activation of the tool management (TOOL)	19
Not used as directed	5	Select magazine assignment table (TL-SEL)	19
Switch on, start-up phase, turn off	6	Edit magazine assignment table (TT-EDIT)	20
Switch on	6	DEFPAGE F2	20
Start-up phase	6	Edit tool data (TL-EDIT)	21
Turn off	6	Optional parameter	21
Switch off / Shut down	7	Tool dimensions	21
Operating system setting, system additional, user profiles	8	Tool life acquisition	22
Coordinate systems, zero points, reference points	9	Additional correction values	22
Machine zero point <u>unequal</u> control zero point	9	Special functions	22
Machine zero point <u>equal</u> control zero point	9	Delete magazine assignment table (TT-DEL)	22
Menu overview	10	Delete tool file (TL-DEL)	22
Operating panel keys	12	Search tool (TL-SEAR)	22
The Info system	15	Options (OPTION)	23
Change database	15	RESET	23
Error list	15	Expert Mode	24
System information	15	Parameter entry (PARIN)	24
Start application program	15	DEFPAGE	24
System messages	15	Position display (POSIT)	24
Configuration	15	INPUT	24
NC Mode	16	MM/INCH	24
Create/modify NC program (EDIT)	16	POS-CHG	24
G&M editor	16	AXES	24
Position display (POSIT)	16	PRESET	24
RESTART	16	Directories (DIR)	24
INPUT	17	Delete ident file (DELETE)	25
TOOL	17	Load automatic program (AUTOM)	25
POS-CHG	17	Create/modify default ident file (DEFIDN)	25
G&M-DIS	17	NEWNAME	25
MDI	17	System Applications	26
PRESET	17	Configuration - mainmenu	26
Program specific configuration (PRCON)	17	Diagnosis - mainmenu	26
Program directory (DIR)	17	Technial Data	27
Delete program (DELETE)	17		
Zero point offset (0-OFFS)	18		

Revisions

Version	Date	Additions and changes	Initials
V 1.0	19.11.2004	First edition	Pa/Scho
V 1.1	28.04.2005	Operating panel pictures in the new XPanel style	Pa
V 1.2	12.06.2006	<ul style="list-style-type: none"> ▪ Addition: Shut down Windows XP correctly ▪ Changed menu structure to call the system applications ▪ New menu overview of the XPanel version (PANELX.EXE) ▪ Operating system settings (virus scanner, firewall, updates, internet options) ▪ Technical data hardware additions: New Pentium M (optional) 	Pa
V 1.3	25.07.2006	Further notes	Pa
V 1.4	07.04.2011	Changed: Operating system settings (virus scanner, firewall, updates, internet options)	Pa

Notice

In the creation of this manual, we have made the greatest effort and have taken the greatest care. We reserve the right to make changes to this handbook and to the controller or the programs, which are made necessary by technical progress, without previous notice. In later versions, additional pages may be inserted. We would appreciate your information as to errors in the handbook or how the handbook may be improved.

We accept no responsibility for damage resulting from neglect of the instructions contained in this handbook.

We are neither liable for nor responsible for actual or alleged loss or damage, whether direct or indirect, which is caused by the operated or delivered equipment or the software programs, and which are claimed by a customer or another natural person or a legal entity. This clause includes faulty service, lost business transactions, loss of expected profit or consequential damages which occur due to the use of the equipment sold by us or software generated by us.



We accept absolutely no responsibility for damage due to faulty installation !

This instruction manual, the program descriptions belonging to it as well as other objects sold or supplied with the controller, are protected by copyright. All rights are reserved. This handbook, the programs, and all other copyrighted objects may be neither completely nor partially copied or in any other manner duplicated, without the previous written consent of andron GmbH. Legally created copies, made with the permission of andron GmbH, of a part of or the complete handbook, the computer programs or other copyrighted objects, must have the same copyright notice as the original material.



Before the connection and the start-up of the control, it is imperative that the documentation is carefully read!

Safety notes

Warning notes and symbols

Meaning of the symbols used in this document:

Symbol	Meaning	Symbol	Meaning
	This notice contains general and additional information as well as rules and prohibitions pertaining to damage prevention.		Important information or cross-references to further descriptions.
	Danger notices for personnel and machine damage, i.e. information as well as rules and prohibitions pertaining to personal injury and material damage prevention.		Danger to life !!!

Use as directed

Introduction andron products are developed and produced according to the latest technologies. They are not delivered unless they have been tested for service reliability.
The products may only be used as directed. If they are not used as directed, material damage and personnel injury may result.



andron assumes no liability for damages due to inappropriate use. andron is not liable for payment of damages. The user is liable at his own risk if the products are not used as directed.

The following requirements must be met before using andron products to ensure proper use:

- The corresponding safety instructions for use as directed must be read and understood by all who operate one of our products.
- If the products include hardware, the original condition must not be changed. Software products must not be de-compiled and the source codes must not be changed.
- Damaged or faulty products must not be integrated or put into operation.
- It must be guaranteed that the products have been installed according to the instructions specified in this manual.

Field of applications

The control is used for control panel integration, integration into housing or the door of the switch cabinet or for machine tool housing integration.

It must be ensured that required mounting, installation and environment conditions are fulfilled.

The control can only be used with the configurations described in this manual. Furthermore, the use of a andron software or firmware is necessary.

Each control system must be parameterized and programmed by competent service personnel before operation.

Not used as directed



The control is „not used as directed“ if it is used in a field of application not specified or if it is used under operating conditions or with technical data not specified in this manual.

The control must not be used if it is exposed to operating conditions which do not fulfill the determined environmental conditions, e.g. use with water or with extreme temperature differences or extreme maximum temperatures is not allowed.

Switch on, start-up phase, turn off


Switch on



The switching on of the control as well as the entire system can be realized in different ways, therefore observe the informations of the machine manufacturer!

Start-up phase

1. Switch on the control
Bootphase of the HMI CPU




2. Loading of the HMI operating system




3. Bootphase of the NC CPU
Loading of the NC operating system



4. Start-up of the SERCOS phases from 0 up to 4



5. Control is ready for operation



* Depending of the basic installation

Turn off



To turn off the control as well as the entire system observe also the informations of the machine manufacturer!

Switch off / Shut down




For switching off of the control as well as the whole machine pay attention to the following notes:


To avoid a data lost or a hard disk damage the control must be shut down always in the correct way. That means the operating system must be completely finished before switching of the control resp. the whole machine.

There are different possibilities to shut down the operating system:

1. Click for example in the Windows start menu on **Shut Down** and then in the drop down list on Shut Down.



2. Or Click for example in the Windows start menu on **CNC Shut Down**



3. Directly from the andronic panel it is possible to shut down the control with function key **SH-DOWN (F2)**.



The operating system is shut down by one of this possibilities, so that you can surely switch off the power supply of the control.



Observe also the informations of the machine manufacturer!

Operating system setting, system additional, user profiles, etc.



Microsoft® Windows® XP Professional (SP2) is the installed operating system on the HMI computer of the andronic. Furthermore are essential patches from Service Pack 3 (SP3) installed. In order to guarantee a highest possible system performance, all unnecessary animation, superfluous software additions and other optical gadgets are deactivated. Changes in these settings can slow down the system considerably.



User-Profiles

Three users with corresponding user profile were arranged on the control:

- **administrator** (Full access with administrative rights)
- **cnc-admin** (Reduced administrative rights)
- **cnc-user** (Considerably reduced user rights for the machine user on operating system level)

Please use only one of the three predefined users.



Virus scanner

We recommend the use of an actual virus scanner.

A complete virus scan is executed before the control is leaving our factory. The installation of additional software or the use of USB memory sticks can cause a virus infection of the system. A final virus check must be done before the entire machine is delivered to the end user.



Firewall

In the default setting the Windows® XP firewall is activated. The use of other firewalls is dissuaded urgently.



Microsoft Security Patches

The installed image contains most of the available Microsoft® security patches. It is not possible to install every security patches in the current version, because after every installation extensive software-tests must occur in order to guarantee the perfect function of the entire system

It is forbidden to install any Microsoft® security patch or another update without permission of ANDRON. It is also not allowed to activate the automatically update function in the Windows® security center.

When using the control with not verified software, the guarantee of the control will lost.




Internet access

In the standard configuration the machine user has no internet access. Only with full access and administrative rights you can connect the control to the Internet

The andronic software offers the possibility of remote diagnosis via internet with the program NetViewer. To use this function it is necessary to make a restriction on administrator level so that the machine user has no general internet access.


Coordinate systems, zero points, reference points

Machine zero point unequal control zero point




- | | | |
|---------|------------------------------|--|
| 1 | Machine zero point | |
| 2 | Control zero point | (Setpos) |
| 3 | Zero point workpiece pallet | |
| 4/5/6/7 | Workpiece zero point | (There can be even further relative zero points [G92] from this point on the workpiece.) |
| 8 | Workpiece zero point | (The respective tool length always calculates from this point.) |
| 9 | Tool changer reference point | Attention: Observe difference between full radius and shank cutter! |
| 10 | Charger position | |

Machine zero point equal control zero point




- | | | |
|---------|------------------------------|--|
| 1 | Machine zero point | |
| 2 | Control zero point | (Setpos) here Setpos = 0 |
| 3 | Zero point workpiece pallet | |
| 4/5/6/7 | Workpiece zero point | (There can be even further relative zero points [G92] from this point on the workpiece.) |
| 8 | Workpiece zero point | (The respective tool length always calculates from this point.) |
| 9 | Tool changer reference point | Attention: Observe difference between full radius and shank cutter! |
| 10 | Charger position | |

Menu overview



menu_overview1.cpps




Operating panel keys



andron supports the control with a basic PLC program for the operating and control functions described below. It is possible that the machine manufacturer delivers a own PLC program with different functions and extensions. If there are no further informations the following description is valid.

Feed step switch



With this step switch you can modify the feed rate in manual and automatic mode between 0% and 125%. A switchover between the speed keys "0", "Feed step switch" and "100" is always possible within the operating modes.



- 0 Rapid traverse/Creep feed 0%:** The rapid traverse or the creep feed rate is set to 0% for all operating modes (manual, automatic or MDI mode), which leads to an immediate stop of the selected axes (depending on the brake reaction of the drives). No more positioning command is carried out. For example, the execution of started NC block programs with traversing instructions is stopped until the key "100" or the key "Feed step switch" (observe switch position) is pressed.
- Feed step switch:** The rapid traverse or the creep feed rate can be set from 0% to 125%, according to the feed step switch position, for all operating modes (manual, automatic or MDI mode). The step switch has a multiple function. In position "0%" the axes stop; in position "100%" the axes move at the defined rapid traverse or creep feed rate. From position 100% to 125% you can raise the defined speed in percent up to a maximum of 125%.

- 100 Rapid traverse/Creep feed 100%:** The rapid traverse or the creep feed rate is set to 100% for all operating modes (manual, automatic or MDI mode).

Spindle speed step switch


With this step switch you can modify the spindle speed between 50% and 125%.

- Spindle stop:** The selected spindle is stopped. A restart of the corresponding spindle is only possible by the key "NC START" (e.g. MDI mode: S10000 M3).
- I Spindle I:** The key "Spindle 1" is free programmable. It can be used for the activation of the spindle control 1, for example.
- II Spindle II:** The key "Spindle 2" is free programmable. It can be used for the activation of the spindle control 1, for example.



Zustands-LEDs


- I** Supply voltage 24 V DC is applied at the operating panel.
- II** Feed release is missing or or was removed.
- III** Keyboard lock is shown.
- IV** A PLC error message is active.



Keylock switch


The keylock switch has 3 positions which are provided for the following functions:

- Key inserted:** Hand-, automatic-, MDI and set up mode: In the set up mode it is possible to work with reduced speed at opened machine cabinet.
- Key removed:** Keyboard lock: All keys are locked, with exception of the key **NC Stop** and **NC Reset**.
- Key inserted (different orientation):** Hand-, automatic-, MDI mode:



Absolute, relative and reference point keys

The control takes three different types of position for each axis into account.



The reference points of the axes are already defined from the machine manufacturer. The absolute and relative positions can be set by the machine operator (SET) according to requirements. They can be moved (MOVE) or set (SET) at another position for each single axis, i.e. each preselected axis, or for several axes (ALL), i.e. the axes defined in the EEPROM in the defined succession. The reference points can only be moved.

- MOVE** With this key you can move single or several axes to the relative zero, absolute zero or reference point .
- SET** With this key you can set the relative or absolute zero for single or several axes.



Reference point

All axes have a machine-related reference point or zero. These can be automatically moved in succession in the operating mode HAND either for each single axis or for several axes (axes and succession definable in the EEPROM).

Procedure for one axis:

>> Preselect the axis >> Push the button REFERENCE POINT >> Push the button MOVE

Procedure for all defined axes:

>> Push the button REFERENCE POINT >> Push the button ALL >> Push the button MOVE



Relative position

The relative position can be automatically set or moved in the operating mode HAND either for each single axis or for several axes. For the setting or the motion of several axes, the axes and the succession are defined in the EEPROM. You can move a relative position only after it has been set. With NC STOP, the relative position is set by the control. Previous relative positions were deleted.

Procedure "Set" for one axis:

>> Preselect the axis >> Push the button RELATIVE ZERO POINT >> Push the button SET -> the relative zero point is set

Procedure "Set" for all defined axes:

>> Push the button RELATIVE ZERO POINT >> Push the button ALL >> Push the button SET -> the relative zero points are set

Procedure "Move" for one axis:

>> Preselect the axis >> Push the button RELATIVE ZERO POINT >> Push the button MOVE -> the relative zero point is moved

Procedure "Move" for all defined axes:

>> Push the button RELATIVE ZERO POINT >> Push the button ALL >> Push the button MOVE -> the relative zero points are moved



Absolute zero point

The absolute zero can be automatically set or moved in the operating mode HAND either for each single axis or for several axes. For the setting or the motion of several axes, the axes and the succession are defined in the EEPROM. The setting of the absolute zero point works like SETPOS = 0 (all axes).

Procedure "Set or Move" for one axis or for all defined axes: (see RELATIVE POSITION)

Machine keys



With the NC-Start key a program is started in automatic mode. For this purpose, the following conditions must be fulfilled:

- The axes must be referenced
- A program has been loaded
- The operating mode "AUTOMATIC" is selected



With the NC-Stop key you stop the automatic execution of a program and simultaneously the relative position of all axes were stored. The stop becomes active at the end of the current program line. This state is signaled by the LED which is constantly on. At the same time the LED of the NC-START key flashes, which allows to continue the program from the stopped point. If you move one or more axes after actuating the key NC STOP in manual mode, the position on NC STOP can be reached again with the key REPOS.

With change of the automatic operating mode, the program can be continued with NC Start.



The NC-RESET key terminates the automatic processing of a program. It is no more possible to continue the processing of the program from the stopped point. For the control unit, the program has been definitely terminated. You can restart the program by NC-START.



This key switches between rapid traverse and creep feed rate in the set-up and standard mode. The appertaining speed values for set-up or standard mode are filed in the EEPROM of the control unit: after the control unit has run up, the set-up mode (parameter set 2) is active with its EEPROM parameters **Set up feed rate** (creep feed) and **Set up rapid traverse**. After a search for reference, the set-up mode is left and the standard mode becomes active. In the standard mode, the following EEPROM parameters are available: **Manual feed rate** (creep feed) and **Manual rapid traverse**. The rapid traverse is indicated by the LED which comes on.

Travel and positioning keys



With the travel key "+" you can move a preselected axis in the positive direction in the manual mode.


- Procedure:
- Step mode due to the preselected feed or fixed path key.
 - Constant traveling, if no feed or fixed path key is activated.



With the travel key "-" you can move a preselected axis in the negative direction in the manual mode.

Procedure: (see travel key "+")

Machine keys



- ✋ The operating mode MANUAL MODE is automatically active after the run-up of the control unit and is signaled by the LED which comes on. In the manual mode it is possible to:
 - to start the reference move
 - traverse or set the absolute or relative zero point
 - move the axes manually
- ➡ The operating mode AUTOMATIC MODE can be activated only after a reference move has been carried out. In the automatic mode it is possible to process a loaded program. The automatic mode is started by operating the NC-START key.

☰ The key SINGLE BLOCK processes an automatic program block by block. After having operated the key, a stop is carried out at the following points:

- In the expert mode after each positioning and I/O command of the program
- In the NC mode at block end of each NC program line. If the residual path display is activated in the EEPROM, the residual path is displayed to the block end.

 The automatic program can be further processed in single block by the NC-START key. If the single block is deactivated, the processing is continued to the end of the automatic program.

⏸ The key OPTIONAL STOP stops the processing of a G&M code program. The G&M code automatic program can be processed to the next M01 function by the NC-START key. If the function OPTIONAL STOP is deactivated, the processing is continued to the end of the automatic program.

↺ With this key (REPOS) the interruption position of an automatic program can be approached again. In this case all individual movements which can be executed in manual mode are summed up to a one travel distance. This travel distances are moved back to the interruption position in inverse order.


Proceeding:

- >> Program abort in the operating mode automatic by actuating the key NC stop. >> Change of operating mode to manual mode.
- >> Travel in manual mode by pre-selection of the desired axis and acknowledging the traverse keys "+" or "-" (RePos LED is blinking).
- >> Actuating the key REPOS: Re-approaching of the interruption position in inverse order of the individual travel distances.
- >> Change of operating modes to the automatic mode. >> Actuating the NC start key: the automatic program is continued from the interruption position on.


⏹ In the operating mode MDI (manual data input) it is possible to carry out a up to three G&M codes via an overlaid edit window. The key cannot be selected, because it is activated over the operating interface.

Proceeding:

- >> Press the function key F7 (MDI function in the andronic operating interface) >> Enter a G&M code line. The input must be closed with ENTER.
- >> After having operated the NC-START key, the entered program line is executed.



Travel keys



↔ With this key you can carry out a defined linear or rotational feed. The feed value is stored in the file "Parametersettings.ini" and can be changed in the program SYSCONFIG. In order to carry out a feed, activate the fixed path key and an axis. Now you can cover the entered feed value via a jog direction key (+/-)


⌄ By selecting the handwheel key, you can carry out a motion of the axis via handwheel in the desired resolution (handwheel increment), having first preselected the axis and operated the feed key. This is only possible in the operating mode HAND.

01
001
0001 These keys allow a movement in the dimensions 0.1, 0.01 and 0.001 mm or inch. The activation of a feed key is confirmed by a light emitting diode. By selecting another feed key, the feed selected before becomes inactive. This is only possible in the operating mode HAND.

Vorgehensweise:

- >> Select the desired feed >> Preselect the desired axis >> Press the corresponding travel direction key (+/-)
 - >> Every time you press a travel key, a jogging is carried out at the feed value
- To use this function it is necessary to activate the incremental width in the EEPROM.

Manual travel keys




The manual travel keys consist of the axis keys A, B, C, X, Y and Z. The preselection of the required axis takes place by operating the corresponding key and is indicated by a light emitting diode (diode comes on). You can deactivate an axis by operating the key once again (light emitting diode goes off). You can move an axis by preselecting it and operating a travel key. The axis moves as long as the jogging key is pressed. If a limit switch is approached when moving an axis, the corresponding axis drive stops immediately. The LED of the axis selection key and the LED of the jog direction key, by which the limit switch has been approached last, flash. This indicates that you can depart the limit switch by the jog direction key which is not flashing. Once the limit switch is free again, both light emitting diodes go off. If an axis is preselected, which is not defined in the EEPROM of the control unit, the LED of the selected axis flashes and an error message is displayed, which disappears after correct axis preselection.

The Info system

The Info system (INFO) can be called up in all operating modes with the function key F1.

With the info selection box, following informations, news and programs are accessible:
(Select and start with F1 [SELECT] or ENTER)



Change database

With **ACCPT** (Accept) or **ENTER** it is possible to select a database path from the preselected paths.



With the **SYSTEM CONFIGURATOR** it is possible to generate a new database. Further configurations can be done with the **DATABASE MANAGER**.

Error list

Possible error messages of the control will be displayed in plain text with the error group, error number, date and time.

With **ERR-NR** error group and error numbers can be entered and displayed in plain text
VERS (Version) displays the version number of the error list.

System information

The software versions of all software modules and the control number will be displayed.

Start application program

Out of this menu the following programs can be executed:

- **DATABASE MANAGER**: Program for managing the database.
- **SYSTEM CONFIGURATOR**: Program to configure system specific parameters like language or database path.
- **POSITION ANALYSER**: The traversing path analysis gives a rough overview of a programmed contour. After the automatic start of a program, with the call up of the traversing path analysis parallel to the running of the machine, up to four selected axes can be displayed.
- **G+M EDITOR**: Start of the G+M editor

System messages

System messages will be displayed. **ACT.MES** (actual message) jumps to the message with the highest priority (only with multiple screen pages).

Configuration

Fixed path key **MM/INCH**: Switch linear fixed path key and position menu between **MM** and **INCH**.

NC Mode




The G&M code program conforming to DIN 66025/ISO 6983 is a widely-used standard, and the most frequently used type of tool machine programming. The G&M code converter is used to produce the control code required for processing in automatic mode from the existing NC-SET.

The andronic 2060 software „FlexProg“ is an addition to the conventional G&M code programming. (see G&M code programming instructions).


Create/modify NC program (EDIT)

Enter program names (maximum 20 alphanumeric characters) or open selection window with the cursor keys (\uparrow/\downarrow), select desired program name, and accept it with the ENTER key. In case a program had been previously generated or processed, its program name appears on the input line.



G&M editor

With the acceptance of the program name, G&M editor will be called up. The program will be generated here.




A detailed description of the editor you can find in the online help of the editor (function key F1)

Position display (POSIT)

RESTART (Simulation record) This function makes it possible to set main programs into an G&M program. The requirement is that an G&M program has been loaded into the controller, the controller is in the automatic operating mode, and the transferred G&M program matches the G&M source.

1. Actuate the function key RESTART. The simulation record window will open.
2. The cursor is positioned by the operator to the desired line on which the simulation record is to be set, or with F2 DEFZEIL it is jumped to the wished line number.
3. Actuate the function key AUTO. The program line to be set in place is communicated to the NC computer.
4. Start the automatic program with the key "Automatic start". The NC computer simulates the processing (without axes movements) up to the program line to be set.



5. Only now may the (environment) function simulation record be exited with END.
6. With another „NC START“ the currently valid functions as toll or pallet change, clamping (M10/M11) spindle start or spindle positioning, coolant (M7/M8/M9/M13/M14/M50/M51) and the start of the position recording are executed. Then the axes will be traversed to the setting point (tool axis last).
7. The automatic program can be processed from the setting point with a renewed actuation of “Automatic start”.

DEFLINE Positions to any desired line
AUTO The line on which simulation record setting is to be made is transferred to the NC computer
END Concludes the record simulation with reference to the environment; an already executed record simulation, via automatic start, will not be stopped in the main computer.

INPUT (Hand parameter input) to define the fixed path for linear and rotational axes. When restarting the control the default fixed path from the file Parametersettings.ini is used (use SysConfig for data entry). Use this key to reach the quick preparing cycles.

TOOL (Tool management) see the following chapter „Tool management“

POS-CHG (Position display change) Switches the position display between smaller and larger display.

G&M-DIS (G&M code display) Opens a window on the monitor and displays the current G&M code program line of the process.

MDI (Manual data input) A record can be manually entered (via the cursor, function and number keys), and transferred with ENTER. With automatic start, the record will be worked off. The record can be executed several times. By call up of the MDI function, the input line can be empty or can contain the last-entered record. The input of up to three records are allowed.


- If the manual data entry was achieved before the start of after the end of an automatic program, then M, F, S, T, D and E words as well as a limited number of G functions are allowed.
- If the manual data entry was achieved in the automatic operating mode, then interrupts are only allowed with M, F, S, T, D and E words.

PRESET (Control position set) Sets the absolute position in the control coordinate system. With SETPOS it is possible to delete the control coordinate system
 → Machine coordinate system = Control coordinate system.

Program specific configuration (PRCON)

To start the program specific configuration you have to select a program and confirm with ENTER.

Here, look ahead, contour and dynamic parameters can be adjusted.



A detailed description of the parameters you can find in the Look Ahead manual.

Program directory (DIR)

Shows all programs available in the database.

Delete program (DELETE)


Deletes selected programs from the database.

Zero point offset (0-OFFS)

The table contains the absolute displacement parameters for the G functions G54-G59. They can be manually entered or transferred as a position.

There are four zero point offset tables. The first is for the programmable zero points of the machine user. The pages P1 ... P3 are used from the measuring cycles as a tray for the measuring values. Only page P3 can be used for angles values.

DEFPAGE	Jump to a defined page
TEACH	(see below)
PASSW	With entry of a password defined in the menu, it is possible to process write-protected parameters
PRTSCR	Prints the current screen page



Teach

With this function, positions will be read into a menu. The manual teaching procedure allows for the individual teaching of each position parameter in the menu. For this, the axis and the position parameter to be taught must be manually selected. With auto-teach, the position parameters to be taught are already in the menu along with teaching information. The teaching information contains the axis (or axes), the algebraic sign and the representation of the position (mm or inches, absolute or relative). With a teach call up, all position values of the axes corresponding to the teaching information in the position parameters will be entered into the menu.

ABS/REL	Switches, in the controller coordinate system, between absolute and relative position
+/-	Switches the algebraic sign
AXIS	Definition such as MM/INCH, ABS/REL, +/- or individual axes can be selected
ACCP	Accepts the taught values in the corresponding position parameters
AXES	Switches between the defined axis records
MASCHPO	Switches to the machine position
FILE	File selection at job management


Load automatic program (AUTOM)

Select a program name with the cursor keys and confirm with ENTER. Then the following menu appears on the display.

In order to achieve as high a processing speed as possible, the NC program is converted to a controller-internal format. The operator decides whether a new conversion run is necessary, whereby a conversion run will be automatically suggested when a program ...

- has been newly generated
- has been worked into the control
- an available program has been modified



After a possible conversion and loading of the program, the small position display appears on the screen; the program can now be started.



DNC function (DNC)

With this function, G&M code source programs are transferred to the control.

G&M-CNV	(G&M converter) Converts an G&M code source program to a internal format
G&M-CPY	InsNCSource: Tool to read and send G&M code files.



Tool management



Overview of functions

- 100 tool magazine locations,
- any number of tools in the data base,
- free configuration of tool types,
- several tool magazines,
- fixed coding of locations,
- duplo tools,
- tool life control,
- 3 different types of status indication,
- limitation of maximum speed,
- speed control,
- 9 pairs of correction values,
- wear control (option)

Numerous adaptation possibilities at the machine:

- chain or disk magazine, pick-up, manual change in any combination up to a total of 100 locations,
- correction of position for every single magazine location,
- programming of the tool change procedures in NC block format

Different options:

- tool can be changed, despite tool life has expired ,
- interruption of the NC program during speed reduction of the tool management,
- in case of tool magazine problems, all tools can be changed manually without intervening within the tool management,


Activation of the tool management (TOOL)

The tool management is activated in the position menu and is displayed with the following basic menu.



Select magazine assignment table (TL-SEL)


The active magazine assignment table is displayed and a new one can be selected, if **no** tool is in the spindle.



Edit magazine assignment table (TT-EDIT)

The magazine assignment table contains the assignment of the T-number and of the tool (tool designation) to a magazine location and the reference to a duplo tool. The magazine assignment tool can be accessed via the position menu, F4 „TL-EDIT“, F3 „TT-EDIT“. Here, an already present magazine assignment table can be edited or a new one can be created.

- The T-number is the tool number used in the G&M code program. A tool can have different T-numbers in different magazine assignments.
- The number of the duplo tool only refers to a duplo tool with the same radius, which is used if the status of the selected tool does not permit that the tool is used (Tool disabled). The duplo tool must be entered in the same magazine assignment table and have the same type of tool.
- Tool size: the value of the size means the number of the covered half places. (That means that one tool of the size 1 covers 2 half places, exactly one place, tool of the size 2 towers above each side a half place.)



- You can select and activate the magazine assignment in the tool management main menu with F2 „SELECT“.

The menu is operated via a line cursor. When activating the magazine management, the menu of the first 10 tools is displayed and the cursor is positioned in the first line. All further menus tool of the tools 11-20, 21-30 etc. up to 91-99 can be displayed with page-up / page-down.

Line cursor: The cursor marks the whole line, it can be moved up and down with the cursor keys. Only by selecting the corresponding line with F3 T-EDIT or Enter the input fields for T-number, WZ designation and duplo tool number can be reached with the cursor keys up/down. If a line is selected, this selection can be cancelled adopting changes by pressing Escape, or accepting the changes by pressing Enter. Strg-X deletes a field resp. an entire line.

DEFPAGE F2 (Defined page) A defined page in the magazine management is selected.

T-EDIT F3 (Line edit) The entries of the selected line can be edited. If the line is selected, the input field can be moved to the right / to the left via Cursor Up / Down. To insert tool names and data call F4 resp. F6. Quit the line which is edited now with Enter / Escape.

TL-EDIT F4 (Tool edit) With this function key a tool data entry is selected from the magazine management, and the program returns to the magazine management, after entering the data and a enquiry „F9-Cancel“ without accepting the changes or with „F10-Save“.

PASSW F5 (Password) With entry of a password defined in the menu, it is possible to process write-protected parameters

SEL-TL F6 (Tool select) A tool which already exists in the data base is transferred to the magazine assignment table.

CUT F7 (Cut tool input) A tool entry is removed and inserted into a different position.

PASTE F8 (Insert tool input) A tool input is inserted from the clipboard to a magazine location. Already existing entries are overwritten and before storing, the T-number and the tool designation must be changed, as these parameter must only appear once in the magazine assignment table. To shift an entry, the old entry must be deleted before inserting the new one.


PRTSCR F9 (Print screen) Prints the current screen page

Magazine position	T number	Tool name (Tool file name)	Tool size	Place size	Place assignm.	Duplo tool T number
MP 1	T 1	Radiusfraeser 10 mm	1	1	T	
MP 2	T 2	Test1	1	1	T	
MP 3	T 3	Radiusfraeser 8 mm	1	1	T	
MP 4	T 4	Radiusfraeser 5 mm	1	1	T	
MP 5	T 5	Schaftfraeser 3.3 mm	1	1	T	
MP 6	T 6	Radiusfraeser 4 mm	1	1	T	
MP 7	T 7	Schaftfraeser 10 mm	1	1	T	
MP 8	T		0	0	T	
MP 9	T 9	Gewindebohrer	1	1	T	
MP 10	T		0	0	T	

Edit tool data (TL-EDIT)

The tool data blocks (data for a tool) are stored in individual files. Thanks to this, individual tools can be used on various tool lists (combination of different tools for one application), without producing double definitions. The menu for the tool data entry is selected via the basic menu of the tool management or via the tool magazine management, it is created and operated just like a conventional menu.

For every tool type an individual menu is available. Therefore a representation of the type can be visualised graphically. In the message line the tool number and the WZ designation are displayed to facilitated a better orientation.



When selecting the tool data input, a pop-up menu appears with the choice of the tool types. After selecting the tool type, the individual tool is selected from all tools via a further pop-up menu.

Optional parameter



- Length
- Radius
- Allowance for length and radius
- Correction for length and radius
- Positive and negative tolerance of the radius
- Tool size
- Status for tool life and tool breakage
- tool life data
- nominal speed
- maximum speed
- data for further pairs of correction values

Tool dimensions

- Length, allowance and wear are added up by the control and set as active length of the tool when changing this tool.
- Radius, allowance and wear are added up by the control and considered correspondingly during the conversion of the program.
- In case of tools of the type milling cutter the total radius in the tool management and the total radius valid at the moment of the conversion are compared after changing the tool. If the changed tool is not within the tolerance range given for the radius, the machining process is aborted with an error message. This happens in the following cases: the radius of the duplo tool diverges inadmissibly from the radius of the original tool; the degree of tool wear is inadmissibly high.

Tool life acquisition

- To use the tool life acquisition, a value for the total tool life must be entered in the corresponding tool file. After the first application of the tool by the machine the status and the remaining tool life is entered automatically in the tool data.
- If a medium warning limit is entered, a message is issued in the position indication when the medium warning limit is reached.
- The remaining tool life can be changed at any time.
- After the tool life has expired, the status of the tool life is set to „0“-blocked- in the next tool change and the tool is not changed again. If a duplo tool is available, this will be used automatically.
- In the magazine configuration the option „Usage of the tool beyond tool life limit“ can be switched on. Then the continuation of machining process is offered, if no duplo tool exists which is released.
- To reactivate the blocked tool, the status of the tool life must be set to „1“-released- and the remaining tool life is deleted, or set to a value greater zero. If the remaining tool life is deleted, the total tool life is valid again.

Additional correction values

Apart from length and radius of the tool, the data of length and radius of eight other pairs of correction values can be activated from the NC program. For this purpose the NC address „D“ or „D0=“ with the number of the desired pair of correction values is used. The first pair of correction values is automatically activated, if no other pair has been activated via D2 (or D0=2) up to D9 (or D0=9).

The correction table it must be filled from the top.

Call in the G&M code: e.g. *T3 M6 D3*

Special functions

- **Speed indication:** If a nominal speed is entered in the tool data, this value is set as spindle speed during the tool change if no speed was programmed in the NC block. The speed given in the tool data is only valid for the corresponding tool. The value displayed is always for spindle 0.
- **Maximum speed limitation:** If a maximum speed is entered in the tool data, this value is set as spindle speed during the tool change, if the speed programmed in the NC block is higher than the maximum speed. In the tool management options it is possible to determine in case of a speed reduction, whether the NC program shall be interrupted with a message or the speed is to be reduce automatically.

Delete magazine assignment table (TT-DEL)

Magazine assignment tables can be deleted individually. When the active magazine assignment is deleted, no tool must be in the spindle and the control must not be in automatic mode.

Delete tool file (TL-DEL)

Deletes individual tools from the data base. After an inquiry the tool is deleted from all magazine assignment tables.

Search tool (TL-SEAR)

This function shows all magazine assignment tables which contain the corresponding tool.

Options (OPTION)

„Tool with expired tool life is inserted after inquiry, if no other tool is available“


This option is intended to facilitate that a tool is used longer than the entered tool life.

0 = no:

If the tool management does not find a tool with remaining tool life, the execution of the G&M code program is cancelled.

1 = yes :

If the tool management does not find a tool with remaining tool life, the G&M code program is only interrupted. value is set as spindle speed during the tool change. This fact is indicated by a message. The execution of the G&M code program can be continued with the first released tool without remaining tool life. The NC program can be cancelled with NC-Reset.



„ G&M code program is interrupted by the tool management in case of speed reduction“

If a value for the maximum speed of the current tool is entered and the speed programmed in the G&M code program is higher than the maximum speed the speed of the spindle is reduced automatically.

0 = no The spindle speed is reduced to the maximum speed of the tool without interruption of the G&M code program.

1 = yes In case of a speed reduction the G&M code program is interrupted with a message to provide the possibility to decide whether to cancel the program or to continue at reduced speed. A new NC start continues the G&M code program at reduced speed.

„Suppress tool change sequences. All tools are changed manually.“

To guarantee the operative ness of the machine in case of damages of the mechanics for the tool change, all tool change sequences can be forced to manual change without need to change the magazine configuration and the magazine assignment table.


0 = no Standard operation

1 = yes All tool changes are executed as „Manual change“.

RESET

„RESET of the error state of the tool change has not been cancelled in the defined state !! Attention ! It is absolutely necessary to check the tool in the spindle and the tool in the position menu“

The tool change is monitored internally by the control. If, due to a power cut or similar events, an undefined state should occur during the tool change, the following tool change is blocked. In this case, a tool change leads to a program abort and the error message „Tool change has not been cancelled in defined state !! Check tool management and reset error in F4-TOOL/F9-OPTION.“. The person operating the machine must check the tool management and compare it with the actual state of the tool magazine and the spindle and enter a „1“ in this option. The next tool change can be carried out again.



Expert Mode



In the **EXPERT MODE**, programming on the machine is restricted to the dialogue-led and graphically-supported entry of geometrical and technological parameters in a menu. The machine operator does not have to worry about axis movements. He enters the work piece related data. The calculation of the required axis movements is performed by the machine builder developed anlog-C program.

The tool and work piece specific data is managed in a database under ident numbers. These menu-driven programs are developed using the anlog-C programming system.

Parameter entry (PARIN)


Enter ident file names (maximum 24 alphanumeric characters) or open the selection window with the cursor keys (\uparrow/\downarrow), select desired ident file names, and enter them with the key ENTER. In case an ident file had been generated or processed previously, this name will be displayed on the entry line. Select desired menu and acknowledge with ENTER. Now the parameters can be entered.

DEFPAGE (Defined page) Jump to a defined page

PASSW (Password) With entry of a password defined in the menu, it is possible to process write-protected parameters

PRTSCR (Print screen) Prints the current screen page

NEWNAME Appears after the key F10 (END) has been actuated, and allows the granting of a new name to an ident file.



Position display (POSIT)


INPUT (Hand parameter input) Hand parameters are made available to the NC computer per command and not by means of a file. They are consequently only valid as long as the controller is switched on. As a rule, these parameters are used in the Jog operating (fixed path); they can be made available to the NC computer during the processing of a automatic program, however.

MM/INCH Switches the position display between mm and inches.

POS-CHG (Change position display) Switches between smaller and larger position display.

AXES (Axis record) Switches between the defined axis records, if severals are available

PRESET (Set control coordinate system) Sets the absolute position in the control coordinate system.




Directories (DIR)

PRDIR (Program files) Shows all programs available in the database

IDIR (Ident files) Shows all ident files available in the database

MDIR (Menu files) Shows all menus available in the database

DIDNDIR (Default ident files) Shows all default ident files available in the database




Delete ident file (DELETE)

Deletes selected ident file from the database.

Load automatic program (AUTOM)

Select ident file names and program names with the cursor (↑/↓) and acknowledge with ENTER. On the screen, the small position display appears. The program can now be started if the absolute zero point has been previously set.



Create/modify default ident file (DEFIDN)

When generating a new ident file, parameters will be transferred from the default ident file (preset file), in case they have been defined in the menu. In the default ident file, corresponding parameters will be pre-assigned and need not be entered again when generating a new ident file.

Enter default ident file names (maximum 24 alphanumeric characters) or select an available default ident file, and acknowledge with the ENTER key. In case a default ident file had been previously generated or processed, its name appears on the input line. Select a menu and acknowledge with ENTER. The parameters are to be entered here.

- DEFPAGE** (Defined page) Jump to a defined page
- PASSW** (Password) With entry of a password defined in the menu, it is possible to process write-protected parameters
- PRTSCR** (Print screen) Prints the current screen page
- NEWNAME** Appears after the key F10 (END) has been actuated, and allows the granting of a new name to a default ident file
- TEACH** see „Teach“ at side 18


System Applications



Über den Menüpunkt der System-Anwendungen (F10 SYSTEM) sind eine Reihe von System-Programmen zugänglich. Die Programme sind unterteilt in Konfigurations- (F2) und Diagnose-Tools (F3).


Configuration – main menu

- F1 andronic history
- F2 Database manager
- F3 System configuration
- F4 EEPROM
- F5 Drive data configuration
- F6 Help for G&M code configuration
- F7 Displaying protocol information
- F8 TabEdit – Cross-/Pitchcompensation
- F9 Autologon
- F10 End



Diagnosis – main menu

- F1 andronic history
- F2 NCClientIO
- F3 NetviewerK
- F4 SaveData
- F5 NCClient
- F6 Position analyser
- F7 Measurm. protocol
- F8 DisplayVars
- F9 RUClient
- F10 End



Technical Data

Control	andronic 2060L	andronic 2060s	
HMI	CPU card	Full-Size Slot CPU (alternatively) Pentium 4 / Pentium M / Celeron M	Half-Size Slot CPU (alternatively) Celeron / Pentium M / Celeron M
	Harddisk	80 GB / 2,5 inch	80 GB / 2,5 inch
	PLC	integrated Soft-PLC (CoDeSys)	integrated Soft-PLC (CoDeSys)
	I/O interfaces	InterBus-S, Profibus-DB	InterBus-S, Profibus-DB
	Operating system	Microsoft Windows® XP® Pro	Microsoft Windows® XP® Pro
	Free PCI slot	1	-
NC	CPU card	Half-Size Slot CPU Celeron / Celeron M	Half-Size Slot CPU Celeron / Celeron M
	NCM card	NC multifunction card	NC multifunction card
	Interfaces	<ul style="list-style-type: none"> ▪ Handwheel ▪ Fast inputs for: Emergency Stop, releases, measuring signals, ... ▪ Contact for "CNC fault" ▪ SERCOS interface (fibre optic) up to 4 rings 	<ul style="list-style-type: none"> ▪ Handwheel ▪ Fast inputs for: Emergency Stop, releases, measuring signals, ... ▪ Contact for "CNC fault" ▪ SERCOS interface (fibre optic) up to 4 rings
	Operating system	andron real-time kernel	andron real-time kernel
General	Protection category	IP 20	IP 20
	Input voltage	100-240 V AC, 50/60 Hz	100-240 V AC, 50/60 Hz
	Power consumption	max. 300 VA	max. 300 VA
	Temperature range	+5°C ... +45°C	+5°C ... +45°C
	Dimensions	293 x 394,5 x 171,5 (WxHxD)	214 x 329 x 171,5 (WxHxD)
Operating panels		ANV03 / ANV04	ANM013 / ANM02
		TFT color display 15" (1024x768)	Machine operating panel
	Protection category	IP 64 (front), IP 20	IP 64 (front), IP 20
	Input voltage	24 V DC	24 V DC
	Power consumption	max. 75 VA	max. 225 VA
	Temperature range	+5°C ... +45°C	+5°C ... +45°C
Dimensions	482,6 x 310,5 x 80,0 (WxHxD)	482,6 x 177,0 x 90,0 (WxHxD)	

